

Comfort 220.2, 250.2, 252.2, 250.2 speed

Operator system for Garage Doors

GB



[[E]
[O]
[S]]
EASY
OPERATING
SYSTEM



Operating Instructions

Marantec 
Torantriebe ➤ automatisch am besten

www.marantec.com

1. Meaning of symbols

Advice



Caution! **Danger of personal injury!**

The following safety advice must be observed at all times so as to avoid personal injury!



Attention! **Danger of material damage!**

The following safety advice must be observed at all times so as to avoid material damage!



Advice / Tip



Check



Reference

Type plate

Type: _____
Art. No.: _____
Product No.: _____

2. Table of contents

1.	Meaning of symbols	2
2.	Table of contents	2
3.	General safety advice	3
4.	Product overview	4
4.1	Comfort 220.2, 250.2, 252.2, 250.2 speed supply package	4
4.2	Door variations	6
5.	Preparation for mounting	6
6.	Installation	7
6.1	Installing the motor unit and drive boom	7
6.2	Installation on the door	8
6.3	Installation on the ceiling	9
6.4	Lighting, signal light connection (optional)	9
6.5	Release	10
6.6	Connection of control elements	11
7.	Hand transmitter	13
7.1	Operation and accessories	13
7.2	Hand transmitter coding	13
8.	Initial operation	14
8.1	Connecting the operator system	14
8.2	Overview of the control unit	15
8.3	Overview of the display functions	15
8.4	Express programming	16
8.5	Function test	18
9.	Extended operator functions	20
9.1	Programming structure for extended operator functions (Example for Level 2, Menu 2)	20
9.2	General overview of the programmable functions	21
9.3	Functions overview for the levels	23
10.	Messages	33
10.1	Malfunctions without error messages	33
10.2	Malfunctions with error messages	34
11.	Attachment	36
11.1	Technical Data for Comfort 220.2, 250.2, 252.2, 250.2 speed	36
11.2	Declaration of Incorporation	37
11.3	EC Declaration of Conformity	38

3. General safety advice



Please read carefully!

IMPORTANT SAFETY INSTRUCTIONS:

IMPORTANT - PLEASE OBSERVE ALL SAFETY INSTRUCTIONS TO PREVENT INJURY TO PERSONS.
PLEASE KEEP THESE INSTRUCTIONS FOR FURTHER USE.

IMPORTANT INSTRUCTIONS FOR SAFE INSTALLATION:

IMPORTANT - INCORRECT INSTALLATION CAN RESULT IN SERIOUS INJURY. PLEASE FOLLOW ALL INSTALLATION INSTRUCTIONS.

Target group

This operator system may only be installed, connected and put into operation by qualified and trained professionals!

Qualified and trained specialist personnel are persons

- who have knowledge of the general and special safety regulations,
- who have knowledge of the relevant electro-technical regulations,
- with training in the use and maintenance of suitable safety equipment,
- who are sufficiently trained and supervised by qualified electricians,
- who are able to recognise the particular hazards involved when working with electricity,
- with knowledge regarding applications of the EN 12635 standard (installation and usage requirements).

Warranty

For an operations and safety warranty, the advice in this instruction manual has to be observed. Disregarding these warnings may lead to personal injury or material damage. If this advice is disregarded, the manufacturer will not be liable for damages that might occur.

Batteries, fuses and bulbs are excluded from warranty.

To avoid installation errors and damage to the door and operator system, it is imperative that the installation instructions are followed. The system may only be used after thoroughly reading the respective mounting and installation instructions.

The operating Instructions are to be given to the door system user, who must keep them safe.

They contain important advice for operation, checks and maintenance.

This item is produced according to the directives and standards mentioned in the Manufacturer's Declaration and in the Declaration of Conformity. The product has left the factory in perfect condition with regard to safety.

Power-operated windows, doors and gates must be checked by an expert (and this must be documented) before they are put into operation and thereafter as required, but at least once a year.

Correct use

The operator system is designed exclusively for opening and closing garage doors.

The operator must be used in a dry place.

The maximum push and pull force must be observed.

Door requirements

The door must:

- stand still alone (by balance of springs),
- run smoothly.

Beside the advice in these instructions, please observe the general safety and accident prevention regulations!
Our sales and supply terms and conditions are effective.

Information on installing the operator system

- Ensure that the door is in good mechanical condition.
- Ensure that the door can stop in any position.
- Ensure that the door can be easily moved in the OPEN and CLOSE directions.
- Ensure that the door opens and closes properly.
- Remove all unnecessary components from the door (e.g. cables, chains, brackets).
- Render any installations inoperable that will no longer be needed after the operator system has been installed.
- Before commencing cabling works it is very important to disconnect the operator system from the electricity supply.
Ensure that the electricity supply remains disconnected throughout the cabling works.
- Adhere to the local protection regulations.
- Lay the electricity supply cables and control cables; these MUST be laid separately. The controls voltage is 24 V DC.
- Install the operator system with the door in the CLOSED position.
- Install all the impulse transmitters and control devices (e.g. remote control buttons) within sight of the door and at a safe distance from the moving parts of the door. A minimum installation height of 1.5 m must be observed.
- Permanently fix the warning signs, which advise of the danger of becoming trapped, at conspicuous locations.
- Ensure that no part of the door extends across public footways or roads when the installation is complete.

Information on commissioning the operator system

After initial operation, the persons responsible for operating the door system, or their representatives must be familiarised with the use of the system.

- Make sure that children cannot access the door control unit.
- Before moving the door, make sure that there are neither persons nor objects in the operating range of the door.
- Test all existing emergency command devices.
- Never insert your hands into a running door or moving parts.
- Pay attention to any parts of the door system that could cause crushing or shearing damage or accidents.

The EN 13241-1 regulations must be observed.

Information on servicing the operator system

To ensure proper operation, the following items must be checked regularly and repaired if necessary.

Before any works to the door system are undertaken, the operator system must be disconnected from the mains.

- Check once a month to ensure that the operator system reverses if the door encounters an obstacle.
Depending on the operational direction of the door, place a 50 mm high/wide obstacle in its path.
- Check the settings of the OPEN and CLOSE automatic cut-out function.
- Check all movable parts of the door and operator system.
- Check the door system for signs of wear or damage.
- Check whether the door can be easily moved by hand.


Information on cleaning the operator system

Never use water jets, high pressure cleaners, acids or bases for cleaning.


4. Product overview

4.1 Comfort 220.2, 250.2, 252.2, 250.2 speed supply package


Standard package




- 1 Comfort 220.2, 250.2, 252.2, 250.2 speed motor unit
- 2 Support plate
- 3 Door link



- 4 Boom clamps (2x)
- 5 Suspension cramps (2x)
- 6 Door connector element
- 7 Door link bracket (2x)




8 Fixing materials for the boom



9 Adapter sleeve

10 Screw 4.0 x 10




11 Screw 6 x 14 (4x)

12 Hexagonal head screw M6 x 20 (2x)


13 Self-tapping screw 6.3 x 16 (4x)

14 Bolt A8 with locking plate

4. Product overview



- 15 Mini hand transmitter
- 16 Micro hand transmitter (only in case of Comfort 250.2, Comfort 252.2 and Comfort 250.2 speed – subject to country-specific alterations)
- 17 Transmission plug
- 18 Sun visor clip flap
- 19 Attachment piece
- 20 Modular antenna
- 21 Sun visor clip



- 22 Warning sign for disengaging
- 23 Warning sticker
- 24 Sticker for express programming


In addition to the components included in the standard package, the following accessories are required for the installation:

- drive boom

Drive booms


The motor unit can be combined with various types of drive boom.

Rail type 1



- 25 Operator rail
- 26 Lintel joining plate, rail type 1
- 27 Screw B4 4.2 x 13 (2x)
- 28 Securing sleeve, short
- 29 Bolt 8 x 12.5
- 30 M6 nut, self-locking

Rail type 2




- 31 Operator rail

4. Product overview


4.2 Door variations

The standard package with the appropriate operator boom is suitable for the following types of door.

Swing out retractable up-and-over door




Sectional door, up to 3 m wide




Special accessories are necessary for the following door type.

Non-swing out retractable up-and-over door



Sectional door, greater than 3 m wide



5. Preparation for mounting



Attention!

In order to guarantee correct mounting, carry out the following checks before installing.

Supply package

- Check the package to ensure that all the parts are included.
- Check that you have all the additional components that are necessary for your particular installation requirements.

Garage

- Check whether your garage has a suitable mains connection and a mains disconnection facility.

Door system



Attention!

For garages without a second entrance: the garage door must be fitted with an emergency release system to allow access to the garage if a fault occurs.

If a release kit is used:

- Check that the door locks are functioning correctly. The door locks may not be disabled under any circumstances.

If a release kit is **not** used:

- Dismantle or disable the door locks.
- Check that the door to be operated fulfils the following conditions:
 - the door must be easily moveable by hand,
 - the door should automatically remain in every position into which it was moved.






Reference:

When using and installing accessories, always observe the specific instructions included with the equipment.

6. Installation

6.1 Installing the motor unit and drive boom

Installation, rail type 1




Attention!



The drive boom (C) must be carefully mounted on the motor unit (F).
Do not use force, as this could damage the gear teeth!

6.1 / 4

- Push the adapter sleeve onto the drive shaft.
- Mount the rail on the motor housing.




Installation, rail type 2




6. Installation

6.2 Installation on the door



Attention!

The drive boom (C) must be carefully mounted on the motor unit (F).
Do not use force, as this could damage the gear teeth!



Caution!



The drive system must be prevented from falling before it has been properly fixed.



Attention!




In order to ensure that the door balance is correct:

- the lintel joining plate for the operator rail must be mounted at the mid point, above the door connector,
- at the highest point reached by the door, the upper edge of the door leaf must be 10 - 50 mm below the horizontal underside of the operator rail.




6. Installation

6.3 Installation on the ceiling



6.4 Lighting, signal light connection (optional)




Connection of signal light (optional)

The connection of a signal light is only possible with a signal light relay (not included in the scope of delivery).



Attention!

To avoid damaging the cable insulation, the cable must be laid in such a way that it does not come into contact with the illuminant in the motor unit.



Reference:

The programming of the signal light is described in level 1, menu 7 and in level 3, menu 7.

6. Installation

6.5 Release



Caution!


- Uncontrolled door movements may occur when the release function is activated:
 - if the door springs are weak or broken;
 - or if the door is not balanced.

When opening the door manually, the carriage can collide with the motor unit.

If the door has been released, it should only be moved at a moderate speed!

- Construct a physical barrier to limit the extent of the door travel in the opening direction.
- Check that the release pull cord is at a minimum height of 1.8 m.
- Attach the "release warning sign" to the release pull cord.


Rail type 1



Rail type 2

6.5 / 2

1. Disconnect door from the motor unit.
2. Reconnect door and motor unit.



6. Installation

6.6 Connection of control elements



Caution!

Danger of electric shock:
Before any cabling works begin, it must be ensured that the cables are disconnected from the power supply.
During cabling works, it must be ensured that the cables remain disconnected from the power supply at all times (e.g. prevent reconnection).




Attention!

In order to avoid damaging the controls:

- The local safety regulations must be complied with at all times.
- It is very important that mains cables are laid separately from control cables.
- The controls voltage must be 24 V DC.
- If external voltages are applied at terminals XP020, XB10 or XB01, the entire electronic system will be destroyed.
- Only potential-free normally open contacts may be connected to terminals 1 and 2 (XB01).
- The shorting plug should never be plugged into the XP020 system socket!

6.6 / 1



Label	Type / function	
XB01	Connection of external control elements without system cabling and two-wire photocell	6.6 / 2, 9.3 / Level 5 / Menu 1
XB10	Connection of external control elements with system cabling	-
XP020	Connection of system photocell or adapter cable for modular antenna	9.3 / Level 8
XB70	Connection of modular antenna	8.1



Reference:

When installing external control elements, or safety and signal equipment, the relevant instructions must be observed.




Advice:

Before connecting a control element to the terminals with system sockets, the corresponding shorting plug must first be removed.

6. Installation

Terminal XB01



Reference:

The programming of the photocell is explained in section 8.4.

Label	Type / function
1	GND (0 V)
2	Impulse
3	24 V DC (max. 50 mA)
70	GND
70 + 71	Two-wire photocell
RX	Receiver for the two-wire photocell
Sb1	External impulse button (if applicable)
TX	Transmitter for the two-wire photocell



Advice:

If a photocell with a standard function or door frame function is used, it must be disconnected from the mains before installing it and taking it into service. After switching on the mains voltage, the photocell is only detected automatically by the controls if the path of the photocell beam remains uninterrupted for at least 5 seconds. Otherwise the photocell must be programmed after installation.

7. Hand transmitter

7.1 Operation and accessories




Caution!

- Children are not allowed to operate the hand transmitters!
- Before operating the hand transmitter, make sure that there are neither persons nor objects in the operating range of the door.

7.1 / 1


Overview.



- A Operating button - large
B Operating button - small
C Battery - transmission control light
D Transmission socket
E Reverse side of the hand transmitter
F Battery 3V CR 2032


7.1 / 2

Replace battery.



7.1 / 3

Accessory sun visor clip.




7.2 Hand transmitter coding

7.2.1 Transfer the coding


7.2.1 / 1

Connect hand transmitter.



7.2.1 / 2


Operating the master transmitter.



- Actuate the master transmitter and hold the button. The transmitter LED lights up.

7.2.1 / 3

Transferring the code.




- Whilst keeping the button on the master transmitter depressed, press the desired button on the other hand transmitter. The LED flashes.

After 1 - 2 seconds, the LED on the newly programmed transmitter lights up permanently. The programming procedure is complete.

- Remove the transmission plug.

7. Hand transmitter

7.2.2 Change coding



- Connect one end of the transmission plug to the hand transmitter.
- At the free end of the transmission plug, short-circuit one of the outer pins with the centre pin adjacent to it (e.g. using a screw driver).
- Press the desired button on the hand transmitter. A new code is then generated by the integrated random coding facility.
The LED flashes quickly.

As soon as the LED lights up permanently, the hand transmitter has been programmed with a new code. The button can then be released and the transmission plug removed.





Advice:

- After the hand transmitter has been re-programmed, the operator system must also be re-programmed to respond to the new code.
- For multi-channel transmitters, the programming process must be carried out for each button separately.


8. Initial operation

8.1 Connecting the operator system



8. Initial operation

8.2 Overview of the control unit



Operating elements

Label	Type / function	
A	Carousel display	8.3
B	OPEN button (+) (e.g. to drive the door to the OPEN position or to increase parameters when programming)	-
C	CLOSE button (-) (e.g. to drive the door to the CLOSED position or to decrease parameters when programming)	-
D	Button (p) (e.g. to switch to programming mode or to save parameters)	-

8.3 Overview of the display functions

LED displays in operating mode

	Photocell or the CESD has been interrupted
	Door moving towards OPEN position
	Door in OPEN position
	Door is at intermediate position
	Door moving towards CLOSED position
	Door in CLOSED position
	Reference point is switched
	Permanent actuation of an external control element
	Remote control is actuated
	Ready for operation

Legend:

LED off	
LED on	
LED flashes slowly	
LED pulses	
LED flashes quickly	
Factory default setting	
Not possible	

8. Initial operation

8.4 Express programming



Attention!

To ensure correct operation, the path of the photocell beam must not be interrupted during the express programming procedure.

Exception: The door leaf in conjunction with a photocell in the door frame area.



Advice:

- For proper initial operation of the operator system, the express programming procedure must be carried out. This applies for initial operation and after a reset.
- A photocell in the door frame area is automatically programmed during express programming. No additional programming steps are necessary for this purpose.
- A door frame position that has been programmed for a photocell can only be deleted by resetting the control.
- After altering the door frame position, a reset must be carried out followed by express programming.

Preconditions

The following conditions must be assured before express programming can commence:

- the door must be in the CLOSED end position.
- the carriage must be connected up.



Advice:

When programming the OPEN and CLOSED door positions, the reference point must be passed.

The controls are programmed using the plus (+), minus (-) and (P) buttons.

If no buttons are pressed within 120 seconds while in programming mode, the controls revert to operating mode. A corresponding message is displayed.



Reference:
















The messages are explained in Section 10.

- Carry out the express programming according to the following procedure.

Legend:

LED off	○
LED on	●
LED flashes slowly	■
LED pulses	◆
LED flashes quickly	◆◆
Factory default setting	■■■■■
Not possible	-

8. Initial operation

 Operating mode	 1. 1x >2s <10s	Start express programming / Programme the door OPEN end position	
	 2.	Drive the door to the OPEN position	
	 3.	Correct the OPEN door position using (+) and (-)	
	 4. 1x <1s	Save the OPEN door position / Programme the CLOSED door position	
	 5.	Drive the door to the CLOSED position	
	 6.	Correct the CLOSED door position using (+) and (-)	
	 7.	Save the CLOSED door position / Programme the remote control	
	 8.	Press the hand transmitter button	
	 9.	Release the hand transmitter button	
	 10. 1x <1s	Save the remote control settings / End the express programming procedure	

8. Initial operation

8.5 Function test

8.5.1 Learning run for determining the driving power



Check:

After express programming and after making changes to the programming menu, the following learning runs and checks must be carried out.

The operator system determines the maximum required driving power during the first two runs after setting the end positions of the door.

- Operate the operator system (with the door coupled) to drive the door once from the CLOSED position to the OPEN position and back to the CLOSED position without interruption.

During this learning run, the operator system determines the maximum push and pull forces and the reserve power required to move the door.

Test:

1.		After pressing the (+) button: The door must open and travel to the saved OPEN end position.
2.		After pressing the (-) button: The door must close and travel to the saved CLOSED end position.
3.		After pressing the hand transmitter button: The operator system must move the door in either the OPEN or CLOSE direction.
4.		After pressing the hand transmitter button while the operator system is running: The operator system must stop.
5.		When the button is pressed again, the operator system moves in the opposite direction.

8.5.2 Checking the automatic cut-out



Caution!

The automatic cut-out must be correctly programmed for the CLOSE and OPEN directions to prevent damage to persons or property.

Automatic cut-out, OPENING

For drive systems where the door has openings in the door wing (diameter of opening > 50 mm):

- Apply a load of 20 kg to the middle of the lower edge of the door whilst the door is running.

The door must stop immediately.

Automatic cut-out, CLOSING

- Place a 50 mm high obstacle on the ground.

- Drive the door towards the obstacle.

The drive system must stop and reverse when it comes into contact with the obstacle.



Advice:

The parameter settings are still saved if the power supply is disconnected. Only a reset causes the driving power settings for the OPEN and CLOSE directions to revert to the factory settings.

8. Initial operation

8.5.3 Checking the photocell

Photocell in the door frame area

- Activate each of the photocells in turn.



Advice:


- The photocell connected in the door frame area must function above the position in which it is installed.
The function below the installation position is suppressed by the control.
- If several photocells are connected, all photocells react analogue with any photocell in the door frame area.

Photocell

- Activate each of the photocells in turn.
- Check all photocells that are connected directly before the CLOSED door position.

9. Extended operator functions

9.1 Programming structure for extended operator functions (Example for Level 2, Menu 2)



9. Extended operator functions

9.2 General overview of the programmable functions

Level	Menu	Factory default setting
Level 1 – Basic functions	Menu 3: Intermediate position OPEN	–
	Menu 4: Intermediate position CLOSE	–
	Menu 7: Relay output	Signal light
	Menu 8: RESET	No reset
Level 2 – Operator settings	Menu 1: Required driving power OPEN	Setting 8
	Menu 2: Required driving power CLOSE	Setting 8
	Menu 3: Automatic cut-out OPEN	Setting 8
	Menu 4: Automatic cut-out CLOSE	Setting 8
Level 3 – Automatic closing timer	Menu 1: Automatic closing timer	Deactivated
	Menu 3: Door open duration	2 Seconds
	Menu 4: Warning time	1 Seconds
	Menu 5: Start-up warning	0 Seconds
	Menu 7: Signal light	Door movement / Warning: flashing Door stoppage: off
Level 4 – Remote programming	Menu 2: Intermediate position	–
Level 5 – Special function	Menu 1: Programmable impulse input	Impulse
	Menu 4: Lighting duration	180 Seconds

Legend:	
LED off	○
LED on	●
LED flashes slowly	◆
LED pulses	◆◆
LED flashes quickly	◆◆◆
Factory default setting	■
Not possible	–

9. Extended operator functions

Level	Menu	Factory default setting
Level 6 - Variable speed	Menu 1: Speed OPEN	Setting 16
	Menu 2: Soft run speed OPEN	Setting 6: Comfort 220.2 Setting 7: Comfort 250.2 Comfort 252.2 Comfort 250.2 speed
	Menu 3: Soft run position OPEN	–
	Menu 4: Speed CLOSE	Setting 10: Comfort 250.2 speed Setting 16: Comfort 220.2 Comfort 250.2 Comfort 252.2
	Menu 5: Smart run speed, CLOSE	Setting 10
	Menu 6: Soft run speed CLOSE	Setting 6: Comfort 220.2 Setting 7: Comfort 250.2 Comfort 252.2 Comfort 250.2 speed
	Menu 7: Smart run position, CLOSE	–
	Menu 8: Soft run position CLOSED	–
Level 8 – System settings	Menu 1: Photocell	Operation without photocell
	Menu 3: Function of the automatic cut-out	Door stops (OPEN) Door reverses a little (CLOSE)
	Menu 4: Operating modes	Press-and-release (OPEN/CLOSE)
	Menu 5: Function of the direction command transmitters	Not active
	Menu 6: Function of the impulse command transmitters	STOP only, then standard sequence

9. Extended operator functions

9.3 Functions overview for the levels



Caution!

Important factory default settings can be changed using the extended functions.
All the parameters must be set correctly to avoid damage to persons or property.

Level 1 – Basic functions																
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Menu 3: Intermediate position OPEN																
	Set using the (+ / OPEN) and (- / CLOSE) buttons "Intermediate position OPEN" – closing function is possible with automatic closing timer															
Menu 4: Intermediate position CLOSE																
	Set using the (+ / OPEN) and (- / CLOSE) buttons															
Menu 7: Relay output (only programmable with optimum signal light relay)																
	A7	B7	C7	D7	E7	F7	G7	H7	I7	J7	K7	-	-	-	-	-
	A8	B8	C8	D8	E8	F8	-	-	-	-	-	-	-	-	-	-



Attention!

After a reset, all the parameters revert to the factory settings.

In order to ensure that the controls operate properly:

- all the required functions must be re-programmed,
- the remote control unit must be re-programmed,
- the drive system must be driven once to the OPEN and CLOSED door positions.



Advice:

- Only the intermediate position that was programmed last can be used.
- If an automatic closing timer is activated (Level 3 / Menu 1), the relay output (Level 1 / Menu 7) cannot be programmed.



Reference:

If changes are made in Menus 3 and 4 in Level 1, a new performance check must be carried out (Section 8.5).

9. Extended operator functions

Menu 7: Relay output

Setting	Function (with optional signal light relay only)	Explanation / Advice	
A7	Signal light	Function	Level 3 Menu 7
B7	Door position: OPEN	-	-
C7	Door position: CLOSED	-	-
D7	Intermediate position OPEN	-	-
E7	Intermediate position CLOSED	-	-
F7	Drive system starts running	Wiping impulse 1 second	-
G7	Problem	-	-
H7	Lighting	Lighting duration	Level 5 / Menu 4
I7	Automatic locking release	Drive system is running	-
J7	Lock release	Drive system starts running / Wiping impulse 3 seconds	-
K7	Push-open security device	-	-

Menu 8: Reset

Setting	Function	Explanation / Advice	
A8	No reset	unchanged	-
B8	Reset control unit *	Factory default setting	-
C8	Reset remote control	Messages are deleted	-
D8	Reset extension, automatic closing timer	level 3, menu 1-7	-
E8	Reset extended operator functions only *	except door OPEN/CLOSED positions and remote control impulse	-
F8	Reset safety devices *	Photocell	-

* All connected and operational safety devices are recognised automatically after resetting.

9. Extended operator functions

Level 2 – Operator settings																		
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		
Menu 1: Required driving power OPEN (sensitivity in increments*)																		
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		
Menu 2: Required driving power CLOSE (sensitivity in increments*)																		
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		
Menu 3: Automatic cut-out OPEN (sensitivity in increments**)																		
	OFF	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		
Menu 4: Automatic cut-out CLOSE (sensitivity in increments**)																		
	OFF	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		

* The higher the setting, the higher the driving power.

** The lower the setting, the more sensitive the automatic cut-out.



Caution!

After switching off or increasing the automatic cut-out increments (Menu 3 and 4):
To exclude any risk of injury, the tests specified in EN 12453 and EN 12445 for validating the correct limitation of force must be performed.

Legend:	
LED off	
LED on	
LED flashes slowly	
LED pulses	
LED flashes quickly	
Factory default setting	
Not possible	

9. Extended operator functions

Level 3 - Automatic closing timer																
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Menu 1: Automatic closing timer																
	A1	B1	C1	D1	E1	F1	G1	H1	-	-	-	-	-	-	-	-
Menu 3: Door open duration (in seconds)																
	2	5	10	15	20	25	30	35	40	50	80	100	120	150	180	255
Menu 4: Warning time (in seconds)																
	1	2	5	10	15	20	25	30	35	40	45	50	55	60	65	70
Menu 5: Start-up warning (in seconds)																
	0	1	2	3	4	5	6	7	-	-	-	-	-	-	-	-
Menu 7: Signal light																
	A7	B7	C7	D7	E7	F7	-	-	-	-	-	-	-	-	-	-



Advice:

- The automatic closing timer can only be programmed if a photocell barrier is connected.
- The functions in Menu 1 can be altered as desired via the time settings in Menus 3 and 4.

Legend:	
LED off	
LED on	
LED flashes slowly	
LED pulses	
LED flashes quickly	
Factory default setting	
Not possible	

9. Extended operator functions

Menu 1: Automatic closing timer

Setting	Door open duration (seconds)	Warning time (seconds)	Automatic closing timer	Other functions
A1	-	-	deactivated	-
B1	15	5	activated	Extension of door OPEN time only through impulse signal (button, hand transmitter)
C1	30	5	activated	
D1	60	8	activated	
E1	15	5	activated	Interruption of the door open duration after the photocell barrier has been driven past
F1	30	5	activated	
G1	60	8	activated	
H1	unlimited	3	activated	Closes after the photocell barrier has been driven past / closing prevention



Advice:

Without a connected photocell or closing prevention device, only parameter A1 can be adjusted.

Menu 7: Signal light

Setting	Door movement / Warning	Door stoppage
A7	flashing	OFF (Electricity saving)
B7	lighting	OFF (Electricity saving)
C7	flashing	flashing
D7	lighting	lighting
E7	flashing	lighting
F7	lighting	flashing



Reference:

The signal light connection can be adjusted in level 1, menu 7.

9. Extended operator functions

Level 4 – Remote programming	
Menu 2: Intermediate position	
	LED 7 flashes slowly -> press the hand transmitter button -> LED 7 flashes quickly

Level 5 – Special function																
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Menu 1: Programmable impulse input - Terminal 1/2																
	A1	B1	C1	D1	E1	-	-	-	-	-	-	-	-	-	-	-
Menu 4: Lighting duration (in seconds)																
	2	5	10	15	20	25	30	35	40	50	80	100	120	150	180	255

Menu 1: Programmable impulse input

Setting	Function (with optional signal light relay only)	Explanation / Advice
A1	Impulse	normally open contact only
B1	Automatic on/off	normally open contact only
C1	closing prevention device	only in CLOSE direction – normally closed contact only
D1	Impulse OPEN	induction loop - normally open contact only
E1	Stop	normally closed contact only



Reference:

- The programming of the special function is dependent on terminal XB01. Terminal XB01 is described in Section 6.6.
- The lighting duration programmed is only active when the relay output (Level 1 / Menu 7) is programmed for lighting (H7).

9. Extended operator functions

Level 6 - Variable speed																
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Menu 1: Speed OPEN (in increments)																
	-	-	-	-	-	-	7	8	9	10	11	12	13	14	15	16
Menu 2: Soft run speed OPEN (in increments)																
	1	2	3	4	5	6 (A)	7 (B, C, D)	8	9	10	11	12	13	14	15	16
Menu 3: Soft run position OPEN																
	Set using the (+ / OPEN) and (- / CLOSE) buttons															
Menu 4: Speed CLOSE (in increments)																
	-	-	-	-	-	-	7	8	9	10 (D)	11	12	13	14	15	16 (A, B, C)
Menu 5: Smart run speed, CLOSE (in increments)																
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Menu 6: Soft run speed CLOSE (in increments)																
	1	2	3	4	5	6 (A)	7 (B, C, D)	8	9	10	11	12	13	14	15	16
Menu 7: Smart run position, CLOSE																
	Set using the (+ / OPEN) and (- / CLOSE) buttons															
Menu 8: Soft run position CLOSED																
	Set using the (+ / OPEN) and (- / CLOSE) buttons															

- A Comfort 220.2
- B Comfort 250.2
- C Comfort 252.2
- D Comfort 250.2 speed



Reference:

If changes are made in Menus 1, 2, 3, 4, 6 and 8 in Level 6, a new performance check must be carried out (Section 8.5).

9. Extended operator functions

Level 8 – System settings																
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
																
Menu 1: Photocell																
	A1	B1	C1	D1	-	-	-	-	-	-	-	-	-	-	-	-
Menu 3: Function of automatic cut-out																
	A3	B3	C3	D3	-	-	-	-	-	-	-	-	-	-	-	-
Menu 4: Operating modes																
	A4	B4	C4	D4	-	-	-	-	-	-	-	-	-	-	-	-
Menu 5: Function of the direction command transmitters																
	A5	B5	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Menu 6: Function of the impulse command transmitters																
	A6	B6	-	-	-	-	-	-	-	-	-	-	-	-	-	-



Attention!

If a photocell is connected, it is automatically recognised by the controls after MAINS ON.
The photocell can be reprogrammed later.

Legend:	
LED off	
LED on	
LED flashes slowly	
LED pulses	
LED flashes quickly	
Factory default setting	
Not possible	

9. Extended operator functions

Menu 1: Photocell

Setting	Photocell 1 (Connection XP020) Door movement, CLOSE	Photocell 2 (Connection XB01 - Terminal 70/71) Door movement, CLOSE
A1		Operation without photocell
B1	Door reverses completely ²	not active
C1	not active	Door reverses completely ²
D1	Door reverses completely ²	Door reverses completely ²

Menu 3: Function of automatic cut-out

Setting	Door movement, OPEN	Door movement, CLOSE
A3	Door stops	Door reverses a little ¹
B3	Door reverses a little ¹	Door reverses a little ¹
C3	Door stops	Door reverses completely ²
D3	Door reverses completely ²	Door reverses completely ²

Menu 4: Operating modes

Setting	OPEN	CLOSE
A4	press and hold	press and hold
B4	automatic closing	press and hold
C4	press and hold	automatic closing
D4	automatic closing	automatic closing

¹ Door reverses a little: The drive system moves the door a short distance in the opposite direction in order to free an obstacle.

² Door reverses completely: The drive system moves the door to the opposite end position.

9. Extended operator functions

Menu 5: Function of the direction command transmitter

Setting	Direction command transmitters	Explanations
A5	not active	The direction command transmitters only give a command when the door is stationary.
B5	STOP only	A moving door is stopped by every direction command transmitter.

Menu 6: Function of the impulse command transmitter

Setting	Impulse command transmitters	Explanations
A6	not active	The impulse command transmitters only give a command when the door is stationary.
B6	STOP only, then standard sequence	A moving door is stopped by every impulse command transmitter. The next command starts the drive system running in the opposite direction (OPEN - STOP - CLOSE - STOP - OPEN).

10. Messages

10.1 Malfunctions without error messages




Error	Cause	Solution
LED 8 does not light up.	- No voltage.	- Check that the mains power supply is operational. - Check the connection to the mains power supply.
	- Thermal overload protection in power transformer was activated.	- Allow the power transformer to cool down.
	- Defective control unit.	- Have the operator system checked.
No reaction on impulse.	- The connection terminals for the "impulse" button were by-passed, e.g. due to a short-circuit or flattened terminals.	- Try temporarily disconnecting any key switches or interior push buttons that are connected to the control unit (Section 6.6): remove the cable from socket XB10, insert the shorting plug and look for cabling errors.
No reaction on impulse from hand transmitter.	- Module antenna is not plugged in.	- Connect the module antenna to the control unit (Section 8.1).
	- The hand transmitter coding does not correspond to the receiver coding.	- Activate hand transmitter again (Section 8.4).
	- Hand transmitter battery is empty.	- Insert new battery (Section 7.1).
	- Defective hand transmitter, control unit electronics or module antenna.	- Have all 3 components checked.
Operator reverses when the door frame photocell is interrupted.	- The programming of the photocell in the door frame area was not performed correctly.	- Carry out a reset of the control (section 9.4 / level 1 / menu F8), repeat express programming again (section 8.4).

10. Messages

10.2 Malfunctions with error messages

Error	Cause	Solution
Message 7 	- If no buttons are pressed within 120 seconds, the programming mode terminates automatically. - OPEN and CLOSED door positions programmed without passing the reference point.	
Message 8 	- Reference point button defective.	- Have the operator system checked.
Message 9 	- No speed sensor impulses, drive system is blocked.	- Have the operator system checked.
Message 10 	- Door movement too stiff. - Door blocked. - Maximum driving power setting is too low.	- Ensure that the door moves easily. - Have the max. driving power (Section 9.3 / Level 2 / Menu 1+2) checked by an expert.
Message 11 	- Excess travel stop.	- Have the operator system checked.
Message 15 	- External photocell interrupted or defective. - Programmed for photocell, but no photocell is connected.	- Remove obstacle or have the photocell checked. - Deactivate or connect the photocell.
Message 16 	- Power sensor for the automatic cut-out is defective.	- Have the motor unit checked.

10. Messages

Error	Cause	Solution
Message 26	 <ul style="list-style-type: none"> - Undervoltage, operator system overloaded at maximum power setting, 16. 	<ul style="list-style-type: none"> - Have the external power supply checked. - Ensure that the door moves easily.
Message 28	 <ul style="list-style-type: none"> - Door movement too stiff or irregular. - Door blocked. 	<ul style="list-style-type: none"> - Check the path of the door and ensure that the door moves easily.
	 <ul style="list-style-type: none"> - Automatic cut-out is set to be too sensitive. 	<ul style="list-style-type: none"> - Have the automatic cut-out facility checked by an expert (Section 9.3 / Level 2 / Menu 3+4).
Message 35	 <ul style="list-style-type: none"> - Electronics are defective. 	<ul style="list-style-type: none"> - Have the operator system checked.
Message 36	 <ul style="list-style-type: none"> - Shorting plug removed, although a stop button is not connected. - Closed circuit is interrupted. 	<ul style="list-style-type: none"> - Connect stop button or insert shorting plug (Section 6.6).

Legend:

LED off	
LED on	
LED flashes slowly	
LED pulses	
LED flashes quickly	
Factory default setting	
Not possible	

11. Attachment

11.1 Technical Data for Comfort 220.2, 250.2, 252.2, 250.2 speed

Electrical data		Comfort 220.2	Comfort 250.2	Comfort 252.2	Comfort 250.2 speed
Nominal voltage *)	V		230 / 260		
Nominal frequency	Hz		50 / 60		
Power consumption	A		1.1		
Power input - operation	KW		0.25		
Power input - stand-by	W	4.2	3.0	3.1	4.0
Operating mode (operating time)	Min.		KB 2	KB 5	KB 2
Control voltage	V DC		24		
Protection category, motor unit			IP 20		
Protection class			II		
*) subject to country-specific alternations					

Mechanical data		Comfort 220.2	Comfort 250.2	Comfort 252.2	Comfort 250.2 speed
Max. push and pull force	N	600	800	1,000	800
Travel speed	mm/sec.		140		220
Opening time (door specific)	sec.		15		9.5

General data		Comfort 220.2	Comfort 250.2	Comfort 252.2	Comfort 250.2 speed
Motor unit dimensions	mm		220x125x395		
Weight	kg	3,8	4,1	4,2	4,5
Sound pressure level	db (A)		< 70		
Temperature range	°C				-20
					+60

Supply package *)
Motor unit Comfort 220.2, 250.2, 252.2, 250.2 speed with integrated electronic controls
Multibit remote control, 868 MHz, Digital 302 mini hand transmitter, 2-channel,
Multibit remote control, 868 MHz, Digital 313 micro hand transmitter, 3-channel
*) subject to country-specific alternations

Features / Safety functions
Reference point technology x
Soft-Start / Soft-Stop x
Delay safety device x
Automatic cut-out x
Blocking protection x
Undervoltage protection x
Excess travel stop x
Electronic travel cut-out x
Connection for pushbuttons, code buttons and key switches x
Connection of potential-free limit switch message system x
Error messages x

Accessories
Modular antenna, 868 MHz, IP 65 x
Mounting supports for sectional doors x
Release kits for swinging doors x
Adapter arm for retractable up-and-over doors x
Fittings for winged doors x
Photocells x
Emergency release x
Relay for flashing signal light when the automatic closing timer is operational x
Retrofit kit for potential-free limit switches OPEN/CLOSE/LIGHT x
Push button x
Key switch x
Code switch x

11. Attachment

11.2 Declaration of Incorporation

We hereby declare that in its design and construction, and in the form as delivered, the product mentioned below complies with the relevant basic requirements of the EC Machinery Directive (2006/42/EC).

This declaration shall no longer be valid if changes are made to the product without our authorisation.

**Product: Garage door operator
Comfort 220.2, 250.2, 252.2, 250.2 speed**

In addition, the partly completed machinery is in conformity with the EC Construction Products Directive 89/106/EC, the EC Electromagnetic Compatibility Directive 2004/108/EC and the EC Low Voltage Directive 2006/95/EC.

- Machinery Directive 2006/42/EC
 - Health and safety requirements applied according to Annex 1:
 - General principles No. 1, No. 1.1.2, 1.1.3, 1.1.5, 1.2.1, 1.2.2, 1.2.3, 1.2.6, 1.3.1, 1.3.4, 1.3.7, 1.3.8, 1.3.9, 1.5.1, 1.5.4, 1.5.6, 1.5.8, 1.5.14, 1.71.6.1, 1.6.3, 1.7
 - EN 60204-1:2007
 - EN ISO 12100-1:2003
 - EN ISO 13849-1:2008
 - Cat. 2 / PLC for the functions of power limitation and end position detection
 - EN 61508:2001
 - EMC electromagnetic compatibility 2004/108/EC
 - EN 55014-1
 - EN 61000-3-2:2006 (2008)
 - EN 61000-3-3:2009
 - EN 61000-6-2:2006
 - EN 61000-6-3:2007
 - Low voltage directive 2006/95/EC
 - EN 60335-1:2002
 - EN 60335-2-103:2004

The relevant technical documentation is compiled in accordance with Annex VII(B) of the Machinery Directive 2006/42/EC. We undertake to transmit, in response to a reasoned request by the market surveillance authorities, this information in electronic form within a reasonable term.

The machinery is incomplete and must not be put into service until the machinery into which it is to be incorporated has been declared in conformity with the provisions of the Machinery Directive 2006/42/EC.

Scope of application of these installation instructions:
Production date 01.03.2012 - 31.03.2013



01.03.2012

ppa. K. Goldstein
Management

Person authorised to compile the relevant technical documentation:

Marantec Antriebs- und Steuerungstechnik
GmbH & Co. KG
Remser Brook 11 · 33428 Marienfeld · Germany

Phone: +49 5247 705-0



11. Attachment

11.3 EC Declaration of Conformity

We hereby declare that in its design and construction, and in the form as brought onto the market by us, the product mentioned below complies with the relevant basic requirements of the EC directives mentioned below.

This declaration shall no longer be valid if changes are made to the product without our authorisation.

Product:

Gate designation

Operator designation

Relevant EC directives:

- Construction Products Directive 89/106/EEC
- Machinery Directive 2006/42/EC
- Electromagnetic Compatibility 2004/108/EC
- Low Voltage Directive 2006/95/EC

The relevant technical documentation is compiled in accordance with Annex VII(B) of the Machinery Directive 2006/42/EC. We undertake to transmit, in response to a reasoned request by the market surveillance authorities, this information in electronic form within a reasonable term.

The machinery is incomplete and must not be put into service until the machinery into which it is to be incorporated has been declared in conformity with the provisions of the Machinery Directive 2006/42/EC.

Installer

Address, postcode, town/city

Date / Signature

English

Original operating instructions protected by copyright.
No part of this manual may be reproduced without our prior consent.
Subject to changes which are in the interest of technical improvements.



83988

Valid from:03.2012
#83988